# 385 Processor May Report Incorrect Address For an L3 Cache Error Machine Check

#### **Description**

The processor may report an incorrect address at NB Machine Check Address Register MSR0000\_0412 when executing a machine check for an L3 cache error. In addition, when disabling an L3 cache index by writing to L3 Cache Index Disable Registers F3x[1C0, 1BC] [Index], the processor may not disable the intended L3 cache index.

## **Potential Effect on System**

Operating system software may take inappropriate action due to an incorrectly reported L3 cache error.

### **Suggested Workaround**

System software should program F3x1B8[23] to 1b before enabling the L3 cache using CR0[30] (CD).

#### **Fix Planned**

No

*107*